



Security Pty Ltd.
P.O. Box 4075
Hoppers Crossing Vic., 3029
A.B.N. 67 584 755 968



USING CODEPAD



The DIGIT keys are used for entering your secret PIN code. You have 10 seconds to enter each digit, and must press the <OK> key when complete. This sequence is required before any panel operations can be performed. These keys can also be used to search for an item to be controlled by selecting the first letter of it's name.



The <OK> key must always be pressed after you have entered your secret PIN code. You have 10 seconds to press the <OK> key after you have completed entering the code.




The <OFF> and <ON> keys are used to turn Off or turn On, the Area (or Area List) named on the Display at the time.



The <END> key is used when you have finished performing the required operations or if you make a mistake while entering your PIN code and want to start again.

ARMING / DISARMING SYSTEM



Enter your secret PIN Code using the digit keys, then press the <OK> key. Each digit pressed will be displayed as a hash (#) character. If you make an error while entering your PIN code, press the <END> key and start again.



If there are no messages to be acknowledged, the Display may first greet and identify you. Note: Greeting can be disabled in V3 or later.



If there is a message to be acknowledged, refer to "Acknowledge an Alarm".

The status of the first Area (or Area List) that you are allowed to control is displayed, with a prompt to perform an ON or OFF operation.



When your operations are complete, you must Logoff the Terminal by pressing the <END> key.